

LOVIBOND® WATER ANALYSIS

TINTOMETER® GROUP



## Lovibond® ShuddhCheck™

Your gateway to better Water Testing

### INSTRUCTION GUIDE- TURBIDITY COLOUR CARD

WORKING RANGE: 0 - 80 NTU

MEASURING RANGE: 0, 0-10, 10-20, 20-40, 40-60, 60-80 NTU



### Test Procedure

1. Take 50ml sample in 50ml glass beaker
2. Place the beaker on the standard icon of Sacchi Disc provided on the right side of the colour card
3. View the icon from the top of the beaker through the solution
4. Compare the darker shades of the icon on which sample is kept with the icons on the left side of the colour card
5. Read the NTU value against the matching icons

No. of Tests: 100

Order Code: IN415050MK

Reorder Code: IN415051MKR

## Tintometer India Private Limited

Door No. 7-2-C-14, 2nd, 3rd & 4th Floor

Sanathnagar Industrial Estate | Hyderabad-500018

Telangana | India



## Notes



- \* Cleaning: Thoroughly rinse out sample container after use.
- \*\* Test reagents are for chemical testing only. Not meant for human consumption; Keep out of reach of children. For industrial use only.



**For more information please reach out to us:**

☎ 1800 599 3891/92 | ✉ [indiaoffice@lovibond.in](mailto:indiaoffice@lovibond.in) | 🌐 [www.lovibond.in](http://www.lovibond.in)

🌐 <https://in.linkedin.com/company/tintometer-india-private-limited>