

LOVIBOND® WATER ANALYSIS

TINTOMETER® GROUP



Lovibond® ShuddhCheck™

Your gateway to better Water Testing

INSTRUCTION GUIDE- FLUORIDE COLOUR CARD

WORKING RANGE: 0 - 3 mg/l (ppm)

MEASURING RANGE: 0, 0.5, 1.0, 1.5, 2.0, 3.0 ppm as Fluoride



Test Procedure

1. Take 2 ml water sample in a plastic vial
2. Add 6 drops of Fluoride reagent and mix well
3. Wait for 2 minutes
4. Notice the colour change and compare it with the colour card provided with the kit
5. The matching colour corresponds to the reading of the fluoride content in mg/l (ppm) in the water sample

This will give the Total Fluoride value directly as mg/l (ppm) in that water sample.

No. of Tests: 100

Order Code: IN415010MK

Reorder Code: IN415011MKR

Tintometer India Private Limited

Door No. 7-2-C-14, 2nd, 3rd & 4th Floor

Sanathnagar Industrial Estate | Hyderabad-500018

Telangana | India



Notes

- * Cleaning: Thoroughly rinse out sample container after use.
- ** Test reagents are for chemical testing only. Not meant for human consumption; Keep out of reach of children. For industrial use only.



For more information please reach out to us:

📞 1800 599 3891/92 | ✉ indiaoffice@lovibond.in | 🌐 www.lovibond.in

🌐 <https://in.linkedin.com/company/tintometer-india-private-limited>