

LOVIBOND® WATER ANALYSIS

TINTOMETER® GROUP



## Lovibond® ShuddhCheck™

Your gateway to better Water Testing

**INSTRUCTION GUIDE- Free Residual Chlorine Colour Card**

**WORKING RANGE: 0 - 3 mg/l (ppm)**

**MEASURING RANGE: 0, 0.2, 0.5, 1.0, 1.5, 2.0, 3.0 as Cl<sub>2</sub>**



### Test Procedure

1. Take 10 ml water sample in a plastic vial
2. Add one tablet of DPD1/DPD1 RAPID to the vial
3. Cap the vial immediately and mix well
4. Notice the colour change and immediately compare it with the colour card provided with the kit
5. The matching colour corresponds to the reading of the Free Residual Chlorine content in mg/l (ppm) in the water sample  
This will give the Free Residual Chlorine value directly as mg/l (ppm) in that water sample.

**No. of Tests: 100**

**Order Code: IN415030MK**

**Reorder Code: IN415031MKR**

## Tintometer India Private Limited

Door No. 7-2-C-14, 2nd, 3rd & 4th Floor

Sanathnagar Industrial Estate | Hyderabad-500018

Telangana | India



## Notes

- \* Cleaning: Thoroughly rinse out sample container after use.
- \*\* Test reagents are for chemical testing only. Not meant for human consumption; Keep out of reach of children. For industrial use only



**For more information please reach out to us:**

📞 1800 599 3891/92 | ✉ [indiaoffice@lovibond.in](mailto:indiaoffice@lovibond.in) | 🌐 [www.lovibond.in](http://www.lovibond.in)

🌐 <https://in.linkedin.com/company/tintometer-india-private-limited>