

LOVIBOND® WATER ANALYSIS

TINTOMETER® GROUP



Lovibond® ShuddhCheck™

Your gateway to better Water Testing

INSTRUCTION GUIDE- IRON DLR COLOUR CARD

WORKING RANGE: 0 – 0.5 mg/l (ppm)

MEASURING RANGE: 0, 0.1, 0.2, 0.3, 0.4, 0.5 ppm



Test Procedure

1. Take 1 ml water sample in a plastic vial and mix it with 1 ml of DI water
2. Add 12 drops of Iron LR Reagent 1 and mix well
3. Add 1 drop of Iron LR Reagent 2 and mix well
4. Wait for 2 minutes
5. Notice the colour change of the liquid surface and compare it with the colour card provided with the kit
6. The matching colour corresponds to the reading of Iron in mg/l (ppm) in the water sample
This will give the Iron value directly in mg/l (ppm) as Fe in that water sample.

No. of Tests: 100

Order Code: IN415120MK

Reorder Code: IN415121MKR

Tintometer India Private Limited

Door No. 7-2-C-14, 2nd, 3rd & 4th Floor

Sanathnagar Industrial Estate | Hyderabad-500018

Telangana | India



Notes

- * Cleaning: Thoroughly rinse out sample container after use.
- ** Test reagents are for chemical testing only. Not meant for human consumption; Keep out of reach of children. For industrial use only



For more information please reach out to us:

📞 1800 599 3891/92 | ✉ indiaoffice@lovibond.in | 🌐 www.lovibond.in

🌐 <https://in.linkedin.com/company/tintometer-india-private-limited>