

LOVIBOND® WATER ANALYSIS

TINTOMETER® GROUP



Lovibond® ShuddhCheck™

Your gateway to better Water Testing

INSTRUCTION GUIDE- IRON HR COLOUR CARD

WORKING RANGE: 0 - 4 mg/l (ppm)

MEASURING RANGE: 0, 1.0, 1.5, 2.0, 3.0, 4.0 mg/l as Fe



Test Procedure

1. Take 10 ml water sample in a glass vial
2. Add 3 drops of Iron HR Reagent and mix well
3. Wait for 2 minutes
4. Notice the colour change and compare it with the colour card provided with the kit
5. The matching colour corresponds to the reading of Iron in mg/l (ppm) in the water sample

This will give the Iron value directly in mg/l (ppm) as Fe in that water sample.

No. of Tests: 100

Order Code: IN415060MK

Reorder Code: IN415061MKR

Tintometer India Private Limited

Door No. 7-2-C-14, 2nd, 3rd & 4th Floor

Sanathnagar Industrial Estate | Hyderabad-500018

Telangana | India



Notes

- * Cleaning: Thoroughly rinse out sample container after use.
- ** Test reagents are for chemical testing only. Not meant for human consumption; Keep out of reach of children. For industrial use only.



For more information please reach out to us:

☎ 1800 599 3891/92 | ✉ indiaoffice@lovibond.in | 🌐 www.lovibond.in

🌐 <https://in.linkedin.com/company/tintometer-india-private-limited>